




# 24-Volt Thermostat and 3-way Zone Valve Wired Directly into the Control Box of the Furnace



For illustration purposes only:  
• Location of thermostat may vary.  
• Not for Heat Pump application.

**NOTE**  
Thermostats must be installed by qualified technician.

